

Endcap Arms for Kayaks- Installation Instructions

Note! Endcap Arms can be installed on 30", 36" or 48" wide Endframes.
They cannot be installed on Half Gondola style endframes.


Walmart Part No. 100605005

Walmart Description

Endcap Arms for Kayaks

Color: Reflection Silver

QTY	SAP#	Description
1		LH EXTENSION POST
1		RH EXTENSION POST
2		LOWER ARM
1		FRONT ARM W/ SIGNHOLDER
1		FRONT ARM
2		STRAP WITH BUCKLE



Visit www.ladarling.com/resources and enter your SAP# for a PDF copy of the instruction sheets.

Each step can be clicked on to jump to that portion of the Assembly Video.

LA DARLING

REDEFINE. RETHINK. RETAIL SOLUTIONS.

LAD DESCRIPTION

OH KAYAK RACK F/ END FRAME

LAD PART NO.

30113501IS

REV.

2

BY

CJS

DATE


03/28/17

Customer Service 1-800-682-5730


PAGE

1 OF 3


Step 1: Insert Extension Posts into top of end frame posts.



Step 2: Insert Lower Arm into the bottom side of the square tube mounted to the extension post. Use snap button to adjust to desired height.



Step 3 & 4: Insert Front Arm and Front arm w/ Signholder into Lower Arms and use snap button to adjust to desired position. Arms should be adjusted for a tight fit on Kayak or Paddle Board to be displayed. (See Page 3)



Step 5: Position Kayak on arms and buckle and tighten straps.



Note! Straps not shown for clarity.

LA DARLING

REDEFINE. RETHINK. RETAIL SOLUTIONS.

LAD DESCRIPTION

OH KAYAK RACK F/ END FRAME

LAD PART NO.

30113501IS

REV.

2

BY

CJS



DATE

03/28/17

Customer Service 1-800-682-5730

PAGE

2 OF 3



For maximum open position, ensure snap button pops through hole.

Snap Button straddling tubes allows for 6" to 9" adjustability

Front arm is adjustable for multiple sizes and styles of kayaks. For maximum adjustability, front arm can be inserted through lower arm so that snap buttons straddle the lower arm tube. Use straps to tighten and secure kayak.