



NOTE! Images are inside of case. Locking bracket will be located inside the case

Step 1: Have the locking bracket at an angle. Push the bracket into the slot with the fixture. (LEFT) Step 2: Push the bracket all the way up to the slots. Place the bracket up to fixture. (RIGHT)





Step 3: Slide the bracket out until the top hole of the bracket line up with the hole in the side panel. Secure bracket with screw and nylon lock nut. The nylon nut should be inside the case. (LEFT)